



Latch goes through the welded pipe on the hinge side of the gate kit. The spring and cap will be on the inside of the gate kit.



Slide the spring on the back side of the latch, then hold the retainer cap and cap on using a hammer

# Country MFG

## Goat Pen Instructions



The panel connectors fasten the top sections of 2 panels together using a connector and a  $\frac{1}{4}$  x 1-1/4 bolt. These will not be installed on panels to be used as doors or end panels.



The all purpose brackets install on the bottom of the door kit to a panel and panel to panel. Shown in the pic

