


3 Point Lift Model AF-3P Assembly Instructions



Step 1: Lay **left & right angles** on a flat surface with bottom of angles pointed inward as show

Step 2: Connect **yoke** to front of **left & right angles** using **3-point lift pins**.

Step 3: Connect **side braces** to **left & right angles** using $\frac{1}{2}$ " x 2" nuts and bolts.

Step 4: Insert $\frac{3}{4}$ " x 4" bolt simultaneously through top of **yoke, top link, and both side braces** (position on inside of yoke).

Step 5: Connect two **lift pipes** underneath the **side angles** using the four U-bolts. Position with **chain loops** pointing upward. Rear U-bolts will also bolt rear brace onto left & right angle.

Step 6: Insert the four **lift chains** through the **chain loops**.

**Connecting 3 Point Lift
To
Adjusta-Flex™ Tine Harrow**

Step 1: After installing 3-point lift onto tractor, position lift over harrow so that **lift chains** are directly over the 5/8" rods.

Step 2: Connect the harrow draw ring to the 3 point lift using 5/8" **hitch pin**.

Step 3: Loop the four **lift chains** around the long 5/8" rods and secure the chain ends with the 5/16" x 1 ¼" nuts and bolts provided.

Note: The two front **lift chains** should be connected between the second and third rows of tines. The two rear **lift chains** should be connected between the sixth and seventh rows of tines.



Country Manufacturing, Inc.

P.O. Box 104

Fredericktown, OH 43019

PH: 740-694-9926

FAX: 740-694-5088